## DAY-TO-DAY VHF MAINTENANCE



- Please replace antenna on first sign of rubber perishing.
- Check contacts in charger base for water ingress and/or corrosion replace if in doubt.
- Check charging contacts on back of radio clean and grease if necessary.
- These recommended maintenance steps apply to most ICOM WATERPROOF VHF handheld radios.